Question 3

During a positional cloning project aimed at finding a human disease gene, linkage data have been obtained suggesting that the gene of interest lies between two sequence-tagged site markers. How can all the known and predicted candidate genes in this interval be identified? What BAC clones cover that particular region?

doi:10.1038/ng1191

UCSC

One possible starting point for this search is the UCSC Genome Browser home page, at http://genome.ucsc.edu. From this page, select Human from the Organism pull-down menu in the blue bar at the side of the page, and then click Browser. On the Human Genome Browser Gateway page, set the assembly pull-down to Nov. 2002. To view a region of the genome between two query terms, enter the terms in the search box, separated by a semicolon. For example, to view the region between STS markers D10S1676 and D10S1675, enter 'D10S1676; D10S1675' in the box marked position and press Submit. Because both of these markers map to a single position in the genome, the genome browser for the region between those markers is returned (Fig. 3.1).

The STS Markers track displays genetically mapped markers in blue and radiation hybrid-mapped markers in black. The markers of interest are called by their alternate names (AFMA232YH9 and AFMA230VA9 in this view) and are at the top and bottom of the interval, respectively (Fig. 3.1, arrows).

The full list of known genes in this display is shown in the Known Genes based on SWISS-PROT, TrEMBL, mRNA, and Ref-Seg track. Scroll down to the middle of the page to view this track (Fig. 3.2). These protein-coding genes are taken from SWISS-PROT, TrEMBL, and TrEMBL-NEW. The genomic position of these proteins is determined by aligning the corresponding Gen-Bank mRNAs to the genome assembly using the BLAT program⁸. To export a list of the genes, or other features, in this region, click the Tables link in the top blue bar. For more information about a particular gene (such as MGMT), click on the gene symbol to get a list of additional links to resources such as Online Mendelian Inheritance in Man (OMIM), PubMed, GeneCards and Mouse Genome Informatics (MGI; Fig. 3.3). Many tracks, including Acembly Genes, Ensembl Genes and Genscan Genes, indicate predicted genes (see Question 7). To view the full set of features in any of these categories, click on the title of that track on the left side of the screen in Fig. 3.2. To view brief descriptions of these tracks, as well as others not mentioned, click on the gray box to the left of the track or scroll down to the track controls and click on the title of a feature of interest. Explanations of the gene-prediction programs can be found in Question 7. Reset the browser to its default settings by clicking on the reset all button below the tracks.

To see the BAC clones used for sequencing, return to the page illustrated in Fig. 3.2. Near the bottom of the page, under the Mapping and Sequencing Tracks, change the Coverage pulldown from hide to full, then change the STS Markers pulldown from full to hide., and click the refresh button. These actions will make the Coverage track visible, while hiding the STS Markers track. In the resulting view, BAC clones are listed individually, with finished regions shown in black and draft regions shown in various shades of gray (Fig. 3.4). For details such as size and sequence coverage of a specific clone, click on the clone accession number (such as AL355529.21, arrow). From this screen, click on the accession number (as shown in Fig. 3.5) to link to the NCBI Entrez document summary for the clone. The full GenBank entry can be viewed by clicking on AL355529 on the Entrez document summary page.

According to NCBI naming conventions, this clone is from the RP11 library and has been named 85C15. RP11 is the NCBI designation for RPCI-11, a commonly used human BAC library produced at the Roswell Park Cancer Institute. More information on the naming conventions of genomic sequencing libraries can be found at the NCBI's Clone Registry (Fig. 3.6; http://www.ncbi. nlm.nih.gov/genome/clone/nomenclature.shtml).

Clone ordering information is also available, at http://www. ncbi.nlm.nih.gov/genome/clone/ordering.html.

The NCBI MapViewer also allows for direct viewing of the region between two markers. One can search chromosome 22 for the region between band numbers 22q12.1 and 22q13.2, or for the region between two mapped genes.

Access the Map Viewer home page by starting at the NCBI home page (http://www.ncbi.nlm.nih.gov) and clicking Map viewer in the list on the right-hand side of the page. To view multiple hits on the same chromosome, type in the search terms separated by the word 'OR'. To see the same region in the human genome between the STS markers D10S1676 and D10S1675, for example, select Homo sapiens from the Select Organism pullowdown, type 'D10S1676 OR D10S1675' in the search box, and hit Go!. At the top of the resulting page (Fig. 3.7), two red tick marks on the chromosome cartoon indicate that the markers map close to each other on chromosome 10. The search results at the bottom of the page show the alternative names for the two markers (AFMA232YH9 and AFMA230VA9) as well as the maps on which they have been placed. To view both markers at the same time, click on the link for chromosome 10 in the chromosome diagram. Fig. 3.8 shows the region around D10S1676 and D10S1675, with the original queries highlighted in pink.

One can also search for a region between two STS markers using the MapView at Ensembl. Start at the Ensembl Human Genome Browser at http://www.ensembl.org/Homo_sapiens/, click on the idiogram of any chromosome to access the MapView, and enter the marker names in the Jump to Contigview section. To use Ensembl to obtain a list of genes (or other annotations) in a defined chromosomal region, click on Export -> Gene List from any ContigView window (Fig. 1.12, center yellow bar).

D10S1675 is not present on the deCODE map. Red lines connect the positions of the marker on the different maps.

The Maps & Options link, in the horizontal blue bar near the top of the page, allows the user to customize the maps and region displayed. To view, for example, the known and predicted genes in this region, as well as the BAC clones from which the sequence was derived, click on the link to open the Maps & Options window (Fig. 3.9). First remove all the maps except Gene and STS from the Maps Displayed box by highlighting them, and selecting << REMOVE. Next, add the Transcript (RNA), GenomeScan, Component and Contig maps by selecting them from the Available Maps box and selecting ADD>>. Make the STS map the master by highlighting it, then selecting Make Master/Move to Bottom. To limit the view such that only the STSs between D10S1676 and D10S1675 are shown, type the marker names in the Region Shown boxes. Finally, remove the check next to Compress Map to see the maps in wider format. Hit Apply to see the aligned maps. In some cases, it may be useful to select a page size larger than the default of 20 to view more data in the browser window.

Fig. 3.10 shows the maps, as specified in the *Maps & Options* window. The green dots to the right of the STS map show all the maps on which the markers appear. This is a fairly long region of chromosome 10, and not every STS marker is shown. In particular, although there are 82 STSs in this region, only 20 are shown by name in this view. For each known gene, the Genes_Seq map


shows all the exons that have been mapped to the genome. Exons for individual known mRNAs are shown on the RNA (Transcript) map. Unless a gene is alternatively spliced, the Genes_Seq and RNA maps will be the same. The GScan (GenomeScan) map shows the NCBI's gene predictions. Any of these genes, known or predicted, are candidates for the disease gene.

The NCBI's assembled contigs, also known as the NT contigs, are found in the Contig map. Blue segments come from finished sequence, orange from draft. These contigs are constructed from the individual GenBank sequence entries shown in the Comp (Component) map. Draft HTG records (phase 1 and 2; see http://www.ncbi.nlm.nih.gov/HTGS/) are displayed in orange and finished HTGs in blue. Most of these GenBank entries are derived from BAC clones. The tiling paths of the BAC clones that were assembled into contigs are clearly visible. One can obtain more details about an entry, including the clone name, by clicking on the accession number to link to Entrez. The clone name is visible directly in the MapViewer if the Comp map is the master. A map can be quickly made the master map by clicking on the blue arrow next to its name.


Because this is a zoomed-out view of the chromosome, individual genes and GenBank entries are difficult to visualize. Zooming in, using the controls in the blue sidebar, will provide a region in more detail. Alternatively, click on the *Data As Table View* in the left sidebar to retrieve all data, including those hidden in this view, as a text-based table (partially shown in Fig. 3.11).











🌺 🕮 🥓 🔯 🚳 Done



